

Supplies For Installation

- (1) Bag of QuickRete per post hole
- (1) Steel post per post hole (2.5" diameter) - Note, a fencing supplier is best costs
- (1) Can GreatStuff Foam per post hole

Area Preparation

- Remove any existing foliage from installation area
- Use a flat shovel to level the grade (so the monument sits flat)
- Position the monument in the crate
 - Once in place, take the time to drive by & be certain you get maximum visibility)

Installation

- Lay the monument on the ground in the crate (this keeps it clean)
- Measure the distance between the receiving holes in the base of the monument
- Dig holes at least 36" deep
 - If you run into a problem, 24" deep is okay, but make hole wider
- Insert steel pipes into the monument while applying expanding adhesive
 - Twist the steel pipe as you apply adhesive & insert. The adhesive will expand.
- Remove crate (1 x 4's) as needed as you lift into position
 - Note: Use the extra foam packaging blocks to keep the monument above grade
- Mix your QuickRete & fill in the footers
 - (The foam blocks allow you to fill in the holes without getting concrete on the monument)
- Remove the foam blocks
 - (The steel pipes can slide up & down if the adhesive is still wet)
- Use a Level to check the Monument
 - (Use dirt, packaging foam, etc. to make sure the unit is level)

Completion

- Use bags of topsoil, bark, river rock or any preferred landscape material to build base
 - (Like a baseball pitcher's mound)
- Add vegetation
 - (Boxwoods, etc. that will not overgrow visibility of your monument)

INSTALLATION QUESTIONS?

Call (770) 631-4086

www.CustomFoamFabricators.com